



RAMSAUER®
DICHTSTOFFE

505 SANITÄR GLÄTTMITTEL

(Sanitary Smoother)

CONCENTRATE

Serves for smoothing Ramsauer silicone sealants for sanitary applications and for removing excess sealant.

Characteristics

Ramsauer SANITÄR GLÄTTMITTEL 505 modifies the surface tension of the sealants in such a way that the pasty compounds will be readily workable which cannot be achieved with water only.

Processing

Ramsauer SANITÄR GLÄTTMITTEL 505 must be diluted with water (1 tablespoon to 2 litres of water). Use a spray bottle to spray small quantities of Ramsauer SANITÄR GLÄTTMITTEL 505 onto the sealant requiring finishing touches. Remove any excess material and smoothen the sealant surface by means of a spreader. In order to achieve neat joint edges cover edges with adhesive tape (Ramsauer masking tape). Remove tape immediately after smoothing the sealant. Remove any sealant residues from the substrate immediately in order to avoid the formation of spots. In order to avoid contamination of the smoother with ingredients of the sealant it is recommended to use it only once. Avoid smoother pools on the sealant since this may cause the formation of water spots.

Attention

Use fresh smoother only! Avoid silicone residues in the smoother. Not suitable for acrylic sealants on a dispersion basis, natural stone nor for manufacturing windows. Using Ramsauer SANITÄR GLÄTTMITTEL 505 on natural stone may cause spots or discolouration which cannot be removed by means of conventional cleaners. Not suitable for use with our tile sealant "Fliese 455". If you have any questions in this context consult our application engineering department.

Storage

12 months (in a dry and cool place protected from frost)

Container size

1 litre

Mixing ratio: 1 : 50

Safety advice

Consult our current EC-safety data sheet. Our data sheets can be downloaded from our website www.ramsauer.at at any time.

Liability for defects

The information provided including but not limited to the proposals for processing and using our products are based on our knowledge and experience, usually at the time of going into print. The results of work may deviate from this information depending on the specific circumstances, in particular with respect to substrates, processing and environmental conditions. Therefore, neither this information nor any oral counselling shall constitute warranty or give rise to any liability on whatever legal ground for any specific result of work, unless we acted intentionally or by gross negligence. Ramsauer

warrants that its products will have the technical characteristics according to the Technical Data Sheets up to their expiry date. Product users must consult the latest data sheet which is available upon request. Our current General Terms and Conditions apply which are available for download on our website www.ramsauer.at at any time.

